

Reusables

Care Instructions



For a long shelf life, easy and optimal cleaning $7 \sqrt{2}$

You will need...

- Reusable cups/mealboxes
- Dishwasher
- Detergent and rinse aid
- Rack



General

If possible, clean the reusables immediately after use. If this is not possible, keep the reusable dishes in a cool place until cleaning. Dispose of excess liquid like leftover tea, coffee, soup.

Washing temperatures

Pay close attention to the recommended temperatures for washing and rinsing reusables.

Wash using commercial dishwasher: the maximum dishwasher temperature should be 60°C - 65°C Industry standard rinse temperature: 80°C - 85°C

Cleaning products

Special detergent and rinse aid can help clean and dry plastic materials.

It is important that your detergent and rinse aid are compatible with PC, PP and composite materials and that the proper dosages are used. Please contact us if you have any questions about specific



We recommend to not leave the dirty cups for more than 72 hours. It is not recommended to use reusables with stainless steel cutlery or other more rigid materials than PP.



- Concentrated rinse for all reusables without leaving marks.
- Helps the products to dry faster.







Rack

Special racks are recommended to ensure stability throughout the cycle.

Because the products are lightweight, they may tip over and collect water. The rack also ensures that the reusables receive enough detergent solution and are thoroughly rinsed in the dishwasher. We have PP and steel racks available to accommodate this process. For more information please contact us.

Drying

To achieve spotless drying results for plastic materials, demineralized water and rinse aid are recommended.

Avoid manually drying your plastic reusable dishes. The drying should be done in a low moisture environment or with specialized drying equipment.

> Our PP dishwasher rack can also be used as a storage. Transportation/collection

Storage of reusables

Only visually clean, fully dried, and undamaged reusables should be stacked.

Storage should be in clean containers or otherwise contaminant-free until reused. Our PP rack can also be used for storage.





info@verive.eu

Our steel dishwasher rack

www.verive.eu

Find out more: